


EJ-TMM Series

Expansion joint cover for floors

Floor to floor condition



Dimension Chart

Model	Joint Opening (J.O.)						Total Movement		S.W.	
	at install		allow min.		allow max.		inches	mm	at install	
	inches	mm	inches	mm	inches	mm			inches	mm
EJ-TMM-200	2	51	1	25	5 1/4	133	4 1/4	108	7 3/4	197
EJ-TMM-400	4	102	1	25	7 1/4	184	6 1/4	159	9 3/4	248
EJ-TMM-600	6	152	1	25	9 1/4	235	8 1/4	210	11 3/4	298

Note: J.O. minimum and maximum values are after thermal movement occurs.



9300 73RD AVENUE NORTH
MINNEAPOLIS, MN 55428

PH. (800) 547-2635
WWW.NYSTROM.COM